

Instructions Pole Storage Canister Kit

Contents:

- Locking Door Cap with spring lock,
- Solid End Cap,
- (2) each U-bolts with base Brackets,
- Bag of nuts & washers for U-bolts, and
- Tube of Marine GOOP adhesive sealant (waterproof, UV resistant, permanent sealant, exterior grade).

NOT Provided:

- Schedule 40 PVC pipe tube, OD of kit size ordered, at whatever length desired.
- Additional U-bolts with base brackets, ordered separately.



Assembly:

1. Inspect kit, ensure all parts present.
2. Size PVC pipe tube to desired mount location and poles to be stored, trim to desired length. De-burr cut edges.
3. Clean inside rims of Locking Door Cap and Solid End Cap with light hand sanding.
4. Clean outside surface ends of PVC pipe tube with light hand sanding.
5. Apply adhesive Marine GOOP to Cap rim surface and outside surface of ends of PVC pipe tube, smooth out adhesive over entire surface area of Cap rim for complete bonding, then apply each Cap full-rim-width onto to either end of PVC tube. Let set to dry. Maximum strength of adhesive in about 24 hours.
6. Align PVC tube to mount location, mark bracket positions. Use U-bolt Brackets to precision mark for drill holes.
7. Drill holes for U-bolts.
8. Align U-bolt Brackets over drilled holes. Use Marine GOOP adhesive to hold bottom of Brackets in place.
9. Align PVC tube on Brackets with Locking Door Cap HINGE at bottom of tube.
10. Apply U-bolts in place over PVC tube through Brackets into mounting surface, attach washers and nuts. Tighten nuts lightly until snug for all Brackets being used.
11. With all U-bolts in place and nuts snug, tighten nuts on each bracket to +/- 25Ft.Lbs. Do NOT over tighten too much or damage to PVC tube could occur.

Made in the USA
GeoData Systems Management Inc., Berea, OH 44017-0366 USA
www.GeoDataSys.com

